


# VOYAGER™

7" Tablet Powered by Intel

## QUICK GUIDE



# Voyager

## Tablet Quick Guide



Thank you for choosing the Tablet TM75A. This portable device is designed to take advantage of micro-mobility and direct interaction through touch/pen input and wireless connectivity (Wi-Fi/Bluetooth) to provide distinct and different use experience for both study and entertainment.



### Package Contents

Your package should contain the Tablet you purchased along with the following items. If anything is missing or appears to be damaged, please contact your vendor or agent.

- ☐ Quick Guide
- ☐ USB cable
- ☐ Power Adapter



#### NOTE:

*The package contents above are for reference only. Please take the actual package items as standard.*

# Specification

## Processor

- Intel® Atom™ processor Z2460 1.6GHz

## LCD Display

- 7inch (16:9), 1024X600 TN LCD

## Touch Panel

- 5-points capacitive touch panel

## Storage

- 8/16GB eMMC Memory\*

## Input/ Output (I/O)

- 1 x TF/Micro SD card slot
- 1 x Mini HDMI type C
- 1 x DC-IN Jack
- 1 x MIC/Headphone Jack combo(American type)
- 1 x Micro USB2.0/OTG port without charging status(Type A/B)

## System Memory

- 1 x LPDDR2, 1GB

## TF/Micro SD Card

- Support 128M~32GB

## WiFi/BT

- 802.11 b/g/n, 2.4 GHz antenna
- Bluetooth 2.1+ EDR

## Camera

- 2 x cameras (Front: 0.3M, Rear: 2M)

## Stereo Speaker

- 2 x internal stereo speakers

## Battery

- MBell 3810088
- 1 Cell, lithium polymer, 3.7V, 4100mAh
- Video play: 6 hours
- Music play: 10 hours
- Wi-Fi: 6 hours (with speaker)

## Power Adapter

- Shenzhen Frecom F12W-050200SPAU/  
F12W-050200SPAI/ F12W-050200SPAV/  
F12W-050200SPAC
- Asian Power WA-10P05R/ WA-10P05Fy  
(y=A,B,C,G,K,N,S,T or U)
- Input: 100-240V ~ 50/60Hz 0.3A
- Output: 5V  $\overline{=}$  2A  $\bigcirc \leftarrow \ominus$

## Tablet Weight

- 384g

## Dimension

- 198.8 mm (W) X 130 mm (H) X 12 mm (D)




**NOTE:**

\* The internal storage of the tablet is either 8 or 16GB, please take the actual products as the standard.


*All specifications are subject to change without notice.*

*All rights reserved legal notices privacy and trademarks.*


# Interface Introduction



NO.	Item	NO.	Item
1	Touch Panel	6	Front Camera
2	Speakers	7	Power Button
3	Charging Indicator	8	Volume Up/Down Button
4	I/O	9	Back Camera
5	Front Microphone	--	--



NO.	Item	NO.	Item
A	TF/Micro SD Card Slot	D	Micro USB Port
B	Mini HDMI Port	E	DC-IN Jack
C	Headphone Jack	--	--

 **NOTE:**  
Due to the system design limitation, if the tablet is connected to computer by Micro USB, please pull up the USB cable before turning off the tablet.

## Turn On/Off the Tablet

### Turn On the Tablet

Press and hold the Power button on the top left side of the tablet.

### Turn Off the Tablet


1. Press and hold the Power button until the options menu appears on the screen.
2. Tap OK on the Power Off option menu to turn off the tablet.

## Charging the Battery

Before using your tablet for the first time, you must fully charge the battery.

### Steps:

1. Insert the Power Adapter into a standard AC power outlet.
2. Connect the Power Adapter to your tablet.



## Installing the Storage Card

You can choose the TF/micro SD cards in a wide range of capacities, varying from 128M to 32GB.

### Install TF/Micro SD Card

1. Turn off the tablet
2. Locate the slot for the TF/micro SD card
3. Insert the TF/micro SD card gently

### Remove TF/Micro SD Card


1. Turn off the tablet or Tape (Menu>Settings>Storage>Unmount SD card)
2. Push the TF/micro SD card to eject from the slot
3. Pull out the TF/micro SD card



FRONT



BACK



### Note:

Please insert the TF/micro SD card in the correct direction. Insert in incorrect direction may result in the damages for both tablet and the TF/micro SD card.